


HTL350-01 MAIN CHASSIS UNIT

NO.	PART NO.	PART DESCRIPTION	QTY
01-1	HTL350-FN.B-M10x25-8.8-DIN-2	BOLT	2
01-2	HTL350-HSPG.W10-DIN-2	SPRING WASHER, TANG ENDS	2
01-3	HTL350-022200	WASHER	2
01-4	HTL350-021600	NUT	8
01-5	HTL350-000001	WHEEL	2
01-6	HTL350-W01-6204ZZ-J	BEARING	4
01-7	HTL350-021400	WHEEL HUB	2
01-8	HTL350-010000	MIAN CHASSIS	1
01-9	HTL350-010300	RUBBER GROMMET	3
01-10	HTL350-W05-GXV160UH2-N1F	ENGINE	1
01-11	HTL350-FN.W8-DIN-2	WASHER	24
01-12	HTL350-HSPG.W8-DIN-2	SPRING WASHER, TANG ENDS	13
01-13	HTL350-FN.B-5/16-24x1¼-DIN-2	BOLT	4
01-14	HTL350-020302	BUSH	1
01-15	HTL350-020301	PULLEY	1
01-16	HTL350-FN.B-M8x45-8.8HALF-DIN-2	BOLT	4
01-17	HTL350-IN.N-M8-DIN-2	LOCK NUT	19
01-18	HTL350-FN.N-M8-DIN-2	NUT	5
01-19	HTL350-FN.B-M8x55-8.8HALF-DIN-2	BOLT	3
01-20	HTL350-022000	PIN	1
01-21	HTL350-FN.B-M8x35-8.8HALF-DIN-2	BOLT	1
01-22	HTL350-FN.B-M8x20-8.8-DIN-2	BOLT	8
01-23	HTL350-020500	GEARBOX BRACKET B	1
01-24	HTL350-020400	GEARBOX BRACKET A	1
01-25	HTL350-HF.B-5/16-18x5/8-8.8-DIN-2	HEXAGON FLANGE BOLT	2
01-26	HTL350-010100	SOLEPLATE	1
01-27	HTL350-WOD.W8-GB-2	WASHER	8
01-28	HTL350-032300	LOCK BOLT	2
01-29	HTL350-022100	BUSH	2
01-30	HTL350-021300	SLIDE PLATE	1
01-31	HTL350-021200	SPRING	2
01-32	HTL350-FN.B-M12x45-8.8HALF-DIN-2	BOLT	1
01-33	HTL350-CH.RG32	INTERNAL CIRCLIP	1
01-34	HTL350-W01-6201ZZ-J	BEARING	1
01-35	HTL350-021000	TENSION PULLEY	1
01-36	HTL350-021100	BUSH,TENSION PULLEY	1
01-37	HTL350-020900	TENSION PULLEY ARM	1
01-38	HTL350-FN.W12-DIN-2	WASHER	2
01-39	HTL350-IN.N-M12-DIN-2	LOCK NUT	3
01-40	HTL350-FN.B-M8x25-8.8-DIN-2	BOLT	2
01-41	HTL350-FN.B-M12x60-8.8-DIN-2	BOLT	1
01-42	HTL350-020800	BUSH	1
01-43	HTL350-020700	GUIDE TUBE	1
01-44	HTL350-CHSN.B-M12x50-GB-2	SQUARE NECKBOLT	1
01-45	HTL350-FN.B-M8x30-8.8-DIN-2	BOLT	2
01-46	HTL350-020600	TENSION PULLEY BRACKET	1
01-47	HTL350-CHSN.B-M10x20-GB-2	SQUARE NECKBOLT	2
01-48	HTL350-021800	CATCH	1
01-49	HTL350-FN.W10-DIN-2	WASHER	2
01-50	HTL350-IN.N-M10-DIN-2	LOCK NUT	2
01-51	HTL350-021700	BUCKET	1
01-52	HTL350-650-023100	GRIP	1

HTL350-01 MAIN CHASSIS UNIT

NO.	PART NO.	PART DESCRIPTION	QTY
-----	----------	------------------	-----



Model: HTL350 Drawing No: HTL350-01-A
 Description: MAIN CHASSIS UNIT (400000000)
 Date: 2010.5.18

Drawn: L.C.
 Checked: _____
 Approved: _____



HTL350-02 TRANSMISSION UNIT

NO.	PART NO.	PART DESCRIPTION	QTY
02-1	HTL350-021900	CAP	2
02-2	HTL350-ET.RG15	LOCK WASHER FOR SHAFTS	2
02-3	HTL350-021600	NUT	8
01-5	HTL350-000001	WHEEL	2
02-5	HTL350-021500	FLANGE, FRONT WHEEL	2
02-6	HTL350-CHSN.B-M8x20-GB-2	BOLT	4
02-7	HTL350-FN.W8-DIN-2	WASHER	17
02-8	HTL350-W01-PFT3/4TF-J	BEARING	2
02-9	HTL350-IN.N-M8-DIN-2	LOCK NUT	6
02-10	HTL350-Key.A-4.76x4.76x50.8	KEY	2
02-11	HTL350-020000	TRANSAXLE	1
02-12	HTL350-020100	TRIGGER	1
02-13	HTL350-WOD.W6-GB-2	WASHER	1
02-14	HTL350-HSPG.W6-DIN-2	SPRING WASHER, TANG ENDS	1
02-15	HTL350-FN.B-1/4-28x3/4-DIN-2	BOLT	1
02-16	HTL350-032300	LOCK BOLT	1
02-17	HTL350-021200	SPRING	1
02-18	HTL350-HSPG.W8-DIN-2	SPRING WASHER, TANG ENDS	8
02-19	HTL350-FN.B-M8x70-8.8HALF-DIN-2	BOLT	8
02-20	HTL350-010200	GEARBOX BRACKET	1
02-21	HTL350-020200	GEARBOX PULLEY	1
02-22	HTL350-FHSS.S-M8x20-GB-3	SOCKET SCREW WITH FLAT HEAD	2
02-23	HTL350-W02-SPA1400	V-BELT	1
02-24	HTL350-11X4-10	INNER TUBE	2

HTL350-02 TRANSMISSION UNIT

NO.	PART NO.	PART DESCRIPTION	QTY
-----	----------	------------------	-----



HTL350-03 OPERATION UNIT

NO.	PART NO.	PART DESCRIPTION	QTY
03-1	HTL350-70B-010112E	FUEL TANK CAP	1
03-2	HTL350-HC.N-M6-DIN-2	CAP NUT	4
03-3	HTL350-HSPG.W6-DIN-2	SPRING WASHER, TANG ENDS	10
03-4	HTL350-WOD.W6-GB-2	WASHER	8
03-5	HTL350-032000	BUSH	3
03-6	HTL350-FN.B-M6x20-8.8-DIN-2	BOLT	4
03-7	HTL350-FN.B-M6x16-8.8-DIN-2	BOLT	6
03-8	HTL350-030100	COVER	1
03-9	HTL350-70B-010109	FUEL TANK	1
03-10	HTL350-70B-010110	STRAINER	1
03-11	HTL350-70ND-010115	PACKING	1
03-12	HTL350-85d-010113	FUEL TANK CAP ,BOTTOM	1
03-13	HTL350-70B-000020	FUEL VALVE	1
03-14	HTL350-032900	HOSE BAND	2
03-15	HTL350-032200	FUEL HOSE	1
03-16	HTL350-WOD.W8-GB-2	WASHER	2
03-17	HTL350-HSPG.W8-DIN-2	SPRING WASHER, TANG ENDS	14
03-18	HTL350-FN.B-M8x25-8.8-DIN-2	BOLT	2
03-19	HTL350-947-99921	HANDLE COVER	2
03-20	HTL350-031500	RIGHT LOADING WHEEL LEVER	1
03-21	HTL350-031400	LEFT LOADING WHEEL LEVER	1
03-22	HTL350-FN.B-M8x20-8.8-DIN-2	BOLT	10
03-23	HTL350-CPT80-0319	WASHER	2
03-24	HTL350-000002	LOADING WHEEL	2
03-25	HTL350-031300	RIGHT LOADING WHEEL COVER	1
03-26	HTL350-CHSN.B-M12x40-GB-2	SQUARE NECKBOLT	2
03-27	HTL350-031600	WASHER	2
03-28	HTL350-FN.W12-DIN-2	WASHER	6
03-29	HTL350-IN.N-M12-DIN-2	LOCK NUT	4
03-30	HTL350-FN.B-M12x35-8.8-DIN-2	BOLT	2
03-31	HTL350-031700	BUSH	2
03-32	HTL350-031800	WASHER	2
03-33	HTL350-CHSN.B-M8x25-GB-2	BOLT	2
03-34	HTL350-FN.W8-DIN-2	WASHER	12
03-35	HTL350-IN.N-M8-DIN-2	LOCK NUT	2
03-36	HTL350-031100	FRICION WHEEL SHAFT	1
03-37	HTL350-031200	LEFT FRICION WHEEL COVER	1
03-38	HTL350-032700	GRIP,GEAR SELECTOR ROD	1
03-39	HTL350-030400	GEAR SELECTOR ROD	1
03-40	HTL350-030600	NYLON BUSH	2
03-41	HTL350-030500	BUSH	1
03-42	HTL350-FHSS.S-M8x6-GB-2	GRUB SCREW	1
03-43	HTL350-030900	UNIVERSAL JOINT	1
03-44	HTL350-032100	NUT L.H	2
03-45	HTL350-030800	THREADED BAR	1
03-46	HTL350-FN.N-M10-DIN-2	NUT	1
03-47	HTL350-031000	UNIVERSAL JOINT	1
03-48	HTL350-IN.N-M10-DIN-2	LOCK NUT	6
03-49	HTL350-FN.N-M8-DIN-2	NUT	2
03-50	HTL350-030700	CONNECTOR	1

HTL350-03 OPERATION UNIT

NO.	PART NO.	PART DESCRIPTION	QTY
03-51	HTL350-FN.B-M8x35-8.8-DIN-2	BOLT	2
03-52	HTL350-000003	HAND GRIP	2
03-53	HTL350-032500	CONTROL LEVER	1
03-54	HTL350-032402	CONTROL LEVER	1
03-55	HTL350-032401	CONTROL LEVER	1
03-56	HTL350-032800	ADJUSTING SCREW	3
03-57	HTL350-031900	CONTROL CABLE	3
03-58	HTL350-030000	HANDLE	1
03-59	HTL350-030200	LEFT BRACKET	1
03-60	HTL350-FN.B-M10x30-8.8-DIN-2	BOLT	4
03-61	HTL350-FN.W10-DIN-2	WASHER	14
03-62	HTL350-HSPG.W10-DIN-2	SPRING WASHER, TANG ENDS	4
03-63	HTL350-FN.B-M10x25-8.8-DIN-2	BOLT	4
03-64	HTL350-030300	RIGHT BRACKET	1
03-65	HTL350-HC.N-M10-DIN-2	CAP NUT	1
03-66	HTL350-FNL.N-M10-DIN-2	HEXAGON THIN NUT	1
03-67	HTL350-70ND-060000	THROTTLE LEVER	1
03-68	HTL350-FHSS.S-M6x8-GB-3	SOCKET SCREW WITH FLAT HEAD	1
03-69	HTL350-W04-45x3	O-RING	1
03-70	HTL350-70ND-060003	BOLT	1
03-71	HTL350-FHSS.S-M8x20-GB-3	SOCKET SCREW WITH FLAT HEAD	1
03-72	HTL350-70ND-060004	SLIDER	1
03-73	HTL350-70ND-060001	THROTTLE BODY	1
03-74	HTL350-70ND-060002	THROTTLE GEAR	1
03-75	HTL350-FNL.N-M8-DIN-2	HEXAGON THIN NUT	2
03-76	HTL350-HC.N-M8-DIN-2	CAP NUT	1
03-77	HTL350-032600	THROTTLE CABLE	1
03-78	HTL350-350-000004	BUSH	1
03-79	HTL350-350-000005	SLIDING BEARING	1
03-78	HTL350-70ND-010018	THROTTLE LEVER ASSY	1
03-79	HTL350-9X3.5-4	INNER TUBE	2

HTL350-03 OPERATION UNIT

NO.	PART NO.	PART DESCRIPTION	QTY
-----	----------	------------------	-----



HTL350-04 FLATBED UNIT

NO.	PART NO.	PART DESCRIPTION	QTY
04-1	HTL350-040100	FLATBED BRACKET	1
04-2	HTL350-040000	FLATBED	2
04-3	HTL350-CHSN.B-M8x35-GB-2	BOLT	8
04-4	HTL350-FN.W8-DIN-2	WASHER	8
04-5	HTL350-IN.N-M8-DIN-2	LOCK NUT	8

